



grain evactool

www.montezumarescueinnovations.com

Grain Evacuation Tool (G.E.T.) Instructions

1. Be certain all lockout/tagout and confined space permit procedures are in place BEFORE attempting to rescue an entrapped person.
2. Access and assess subject. Secure subject with harness and rope.
3. Use included fiberglass probes to locate buried extremities.
4. Assemble fiberglass probes to form a circle and then place it around the subject as a template for the G.E.T. panels.
5. Push each individual G.E.T. panel into the grain just enough for each panel to stand alone, repeat until all six panels are in place. Secure with the black webbing strap.
6. Attach the included foot straps to the top of each panel, then step into each foot strap and drive each panel down into the grain while holding the top of the panel from the opposite side to keep it vertical. Repeat until all panels have reached a sufficient depth to isolate the subject, taking care not to push a panel down onto any buried extremities.
7. Remove grain from inside the G.E.T. using the included Grain Portr (or by using whatever means necessary).
8. Remove subject from the G.E.T.

