

The ROPE OUT bag replaces the uncomfortable rope rings that were placed around the chest. It lets you give slack quickly and can be thrown in case of crevasse rescue. The rope end comes out through an eyelet at the bottom of the bag for rescue use. There is a quick snap system to adjust the length easily and the mesh sides accelerate drying.

Key Features

• Clic-clac opening system to adjust • Mesh material for quick drying rope length easily

• Useful for rescue

Additional Information

 Rope can go through top and bottom of bag

Shipping weight | N/A **Bag Dimensions** | 4 L: 13.5x 5.5", 7 L: 15.5x 6.7" Size | 4 Liters, 7 Liters Material | PVC

Tags

Outdoor Climbing, Rope Rescue

Product Code

BOBSAC.RO4 | 4 Liters BOBSAC.RO7 | 7 Liters

